



**AB-41**

**APPLICATION  
BRIEF**

**Software Serial Port  
Implemented with the PCA**

**BETSY JONES**  
ECO APPLICATIONS ENGINEER

August 1988



Order Number: 270531-002

Information in this document is provided in connection with Intel products. Intel assumes no liability whatsoever, including infringement of any patent or copyright, for sale and use of Intel products except as provided in Intel's Terms and Conditions of Sale for such products.

Intel retains the right to make changes to these specifications at any time, without notice. Microcomputer Products may have minor variations to this specification known as errata.

\*Other brands and names are the property of their respective owners.

†Since publication of documents referenced in this document, registration of the Pentium, OverDrive and iCOMP trademarks has been issued to Intel Corporation.

Contact your local Intel sales office or your distributor to obtain the latest specifications before placing your product order.

Copies of documents which have an ordering number and are referenced in this document, or other Intel literature, may be obtained from:

Intel Corporation  
P.O. Box 7641  
Mt. Prospect, IL 60056-7641  
or call 1-800-879-4683

**SOFTWARE SERIAL PORT  
IMPLEMENTED WITH THE  
PCA**

<b>CONTENTS</b>	<b>PAGE</b>
Introduction .....	1
Variables .....	1
Initialization .....	3
Receive Routine .....	3
Transmit Routine .....	7
Conclusion .....	8
<b>APPENDIX</b> .....	<b>A-1</b>





For microcontroller applications which require more than one serial port, the 83C51FA Programmable Counter Array (PCA) can implement additional half-duplex serial ports. If the on-chip UART is being used as an inter-processor link, the PCA can be used to interface the 83C51FA to additional asynchronous lines.

This application uses several different Compare/Capture modes available on the PCA to receive or transmit bytes of data. It is assumed the reader is familiar the PCA and ASM51. For more information on the PCA refer to the "Hardware Description of the 83C51FA" chapter in the Embedded Controller Handbook (Order No. 210918).

### Introduction

The figure below shows the format of a standard 10-bit asynchronous frame: 1 start bit (0), 8 data bits, and 1 stop bit (1). The start bit is used to synchronize the receiver to the transmitter; at the leading edge of the start bit the receiver must set up its timing logic to sample the incoming line in the center of each bit. Following the start bit are eight data bits which are transmitted least significant bit first. The stop bit is set to the opposite state of the start bit to guarantee that the leading edge of the start bit will cause a transition on the line. It also provides a dead time on the line so that the receiver can maintain its synchronization.

Two of the Compare/Capture modes on the PCA are used in receiving and transmitting data bits. When receiving, the Negative-Edge Capture mode allows the PCA to detect the start bit. Then using the Software Timer mode, interrupts are generated to sample the incoming data bits. This same mode is used to clock out bits when transmitting.

This Application Note contains four sections of code:

- (1) List of variables
- (2) Initialization routine

- (3) Receive routine
- (4) Transmit routine.

A complete listing of the routines and the test loop which was used to verify their operation is found in the Appendix. A total of three half-duplex channels were run at 2400 Baud in the test program. The listings shown here are simplified to one channel (Channel 0).

### Variables

Listing 1 shows the variables used in both the receive and transmit routines. Flags are defined to signify the status of the reception or transmission of a byte (e.g. RCV\_START\_BIT, TXM\_START\_BIT). RCV\_BUF and TXM\_BUF simulate the on-chip serial port SBUF as two separate buffer registers. The temporary registers, RCV\_REG and TXM\_REG, are used to save bits as they are received or transmitted. Finally, two counter registers keep track of how many bits have been received or transmitted.


Variables are also needed to define one-half and one-full bit times in units of PCA timer ticks. (One bit time = 1 / baud rate.) With the PCA timer incremented every machine cycle, the equation to calculate one bit time can be written as:

$$\frac{\text{Osc. Freq.}}{(12) \times (\text{baud rate})} = 1 \text{ bit time (in PCA timer ticks)}$$

In this example, the baud rate is 2400 at 16 MHz.

$$\frac{16 \text{ MHz}}{(12) \times (2400)} = 556 \text{ counts} = 22\text{C Hex}$$

The high and low byte of this value is placed in the variables FULL\_BIT\_HIGH and FULL\_BIT\_LOW, respectively. 115H is the value loaded into HALF\_BIT\_HIGH and HALF\_BIT\_LOW.



Listing 1. Variables used by the software serial port. Channel 0

```

;
; Receive Routine
;
RCV_START_BIT_0  BIT      20H.0    ; Indicates start bit
; has been received
RCV_DONE_0      BIT      20H.1    ; Indicates data byte
; has been received
RCV_BUF_0       DATA    30H      ; Software Receive
; "SBUF"
RCV_REG_0       DATA    31H      ; Temporary register
; for receive bits
RCV_COUNT_0     DATA    32H      ; Counter for receiving
; bits

; Transmit Routine:
;
TXM_START_BIT_0 BIT      20H.3    ; Indicates start bit
; has been transmitted
TXM_IN_PROGRESS_0 BIT    20H.4    ; Indicates transmit is
; in progress
TXM_BUF_0       DATA    34H      ; Software transmit
; "SBUF"
TXM_REG_0       DATA    35H      ; Temporary register
; for transmitting bits
TXM_COUNT_0     DATA    36H      ; Counter for transmit-
; ting bits
DATA_0          DATA    37H      ; Register used for the
; test program

;
NEG_EDGE        EQU      11H      ; Two modes of operation
S_W_TIMER       EQU      49H      ; for compare/capture
; modules

;
HALF_BIT_HIGH   EQU      01H      ; Half bit time = 115H
HALF_BIT_LOW    EQU      15H
FULL_BIT_HIGH   EQU      02H      ; Full bit time = 22CH
FULL_BIT_LOW    EQU      2CH      ; 2400 Baud at 16 MHz

```

270531-4

## Initialization

Listing 2 contains the initialization code for the receive and transmit process. Module 0 of the PCA is used as a receiver and is first set up to detect a negative edge from the start bit. Modules 2 and 3 are used for the additional 2 channels (see the Appendix). Module 3 is used as a separate software timer to transmit bits.

Listing 2. Initialization Routine

```

ORG 0000H
LJMP INITIALIZE
ORG 001BH
LJMP RECEIVE_DONE           ; Timer 1 overflow -
                           ; simulates "RI" interrupt

ORG 0033H
LJMP RECEIVE               ; PCA interrupt
;
INITIALIZE: MOV SP, #5FH    ; Initialize stack pointer
                           ; (specific to test program)
INIT_PCA:  MOV CMOD, #00H   ; Increment PCA timer
                           ; @ 1/12 Osc Frequency
           MOV CCON, #00H   ; Clear all status flags
           MOV CCAPM0, #NEG_EDGE ; Module 0 in negative-edge
                           ; trigger mode (P1.3)
           MOV CCAPM3, #S_W_TIMER ; Module 3 as software timer
                           ; mode
           MOV CL, #00H
           MOV CH, #00H
           MOV IE, #0D8H    ; Init all needed interrupts
                           ; EA, EC, ES, ET1
           SETB CR          ; Turn on PCA Counter


```

270531-5

All flags and registers from Listing 1 should be cleared in the initialization process.

## Receive Routine

Two operating modes of the PCA are needed to receive bits. The module must first be able to detect the leading edge of a start bit so it is initially set up to capture a 1-to-0 transition (i.e. Negative-Edge Capture mode). The module is then reconfigured as a software timer to cause an interrupt at the center of each bit to deserialize the incoming data. The flowchart for the receive routine is given in Figure 1.



270531-2

Figure 1. Flowchart for the Receive Routine



Listing 3.1 shows the code needed to detect a start bit. Notice that the first software timer interrupt will occur one-half bit time after the leading edge of the start bit to check its validity. If it is valid, the RCV\_START\_BIT is set. The rest of the samples will occur a full bit time later. The RCV\_COUNT register is loaded with a value of 9 which indicates the number of bits to be sampled: 8 data bits and 1 stop bit.

Listing 3.1. Receive Interrupt Routine

```

RECEIVE:  PUSH ACC
          PUSH PSW
;
MODULE_0: CLR CCF0                ; Assume reception on
          ; Module 0
          MOV A, CCAPM0           ; Check mode of module. If
          ANL A, #01111111B      ; set up to receive negative
          CJNE A, #NEG_EDGE, RCV_START_0 ; edges, then module
          ; is waiting for a start bit
;
          CLR C                  ; Update compare/capture
          MOV A, #HALF_BIT_LOW   ; registers for half bit time
          ADD A, CCAP0L         ; to sample start bit
          MOV CCAP0L, A         ; Half bit time = 115H
          MOV A, #HALF_BIT_HIGH
          ADDC A, CCAP0H
          MOV CCAP0H, A
          MOV CCAPM0, #S_W_TIMER ; Reconfigure module 0 as
          POP PSW                ; a software timer to sample
          POP ACC                ; bits
          RETI
;
RCV_START_0: CJNE A, #S_W_TIMER, ERROR_0 ; Check module is
          ; configured as a software
          ; timer, otherwise error.
          JB RCV_START_BIT_0, RCV_BYTE_0 ; Check if start bit
          ; is received yet.
          JB P1.3, ERROR_0         ; Check that start bit = 0,
          ; otherwise error.
          SETB RCV_START_BIT_0    ; Signify valid start bit
          ; was received
          MOV RCV_COUNT_0, #09H   ; Start counting bits sampled
;
          CLR C                  ; Update compare/capture
          MOV A, #FULL_BIT_LOW   ; registers to sample
          ADD A, CCAP0L         ; incoming bits
          MOV CCAP0L, A         ; Full bit time = 22CH
          MOV A, #FULL_BIT_HIGH
          ADDC A, CCAP0H
          MOV CCAP0H, A
          POP PSW
          POP ACC
          RETI

```

270531-6

The next 8 timer interrupts will receive the incoming data bits; the RCV\_COUNT register keeps track of how many bits have been sampled. As each bit is sampled, it is shifted through the Carry Flag and saved in RCV\_REG. The ninth sample checks the validity of the stop bit. If it is valid, the data byte is moved into RCV\_BUF.

The main routine must have a way to know that a byte has been received. With the on-chip UART, the RI (Receive Interrupt) bit is set whenever a byte has been received. For the software serial port, any unimplemented interrupt vector can be used to generate an interrupt when a byte has been received. This routine uses the Timer 1 Overflow interrupt (its selection is arbitrary). A routine to test this interrupt is included in the listing in the Appendix.

Listing 3.2. Receive Interrupt Routine (Continued)

```

RCV_BYTE_0: DJNZ RCV_COUNT_0, RCV_DATA_0 ; On 9th sample,
                                           ; check for valid stop bit
RCV_STOP_0: JNB P1.3, ERROR_0
             MOV RCV_BUF_0, RCV_REG_0 ; Save received byte in
             ; receive "SBUF"
             SETB RCV_DONE_0 ; Flag which module received
             ; a byte
             SETB TF1 ; Generate an interrupt so
             ; main program knows a byte
             ; has been received
             ; (Note: selection of TF1 is
             ; arbitrary)
             MOV CCAPM0, #NEG_EDGE ; Reconfigure module 0 for
             ; Reception of a start bit

             POP PSW
             POP ACC
             RETI

;
RCV_DATA_0: MOV C, P1.3 ; Sampling data bits
             MOV A, RCV_REG_0 ; Shifts bits thru CY into
             RRC A ; ACC
             MOV RCV_REG_0, A ; Save each reception in
             ; temporary register
             CLR C ; Update c/c register for
             MOV A, #FULL_BIT_LOW ; next sample time
             ADD A, CCAP0L
             MOV CCAP0L, A
             MOV A, #FULL_BIT_HIGH
             ADDC A, CCAP0H
             MOV CCAP0H, A
             POP PSW
             POP ACC
             RETI

```

270531-7

In addition, an error routine (Listing 3.3) is included for invalid start or stop bits to offer some protection against noise. If an error occurs, the module is re-initialized to look for another start bit.

Listing 3.3 Error Routine for Receive Routine

```

ERROR_0: MOV CCAPM0, #NEG_EDGE ; Reset module to look for
             ; start bit
             CLR RCV_START_BIT_0 ; Clear flags which might
             ; have been set

             POP PSW
             POP ACC
             RETI

```

270531-8

### Transmit Routine

Another PCA module is configured as a software timer to interrupt the CPU every bit time. With each timer interrupt one or more bits can be transmitted through port pins. In the test program three channels were operated simultaneously, but in the listings below, one channel is shown for simplicity. The selection of port pins is user programmable. The flowchart for the transmit routine is given in Figure 2.




Figure 2. Flowchart for the Transmit Routine

When a byte is ready to be transmitted, the main program moves the data byte into the TXM\_BUF register and sets the corresponding TXM\_IN\_PROGRESS bit. This bit informs the interrupt routine which channel is transmitting. The data byte is then moved in the storage register TXM\_REG, and the TXM\_COUNT is loaded. This main routine is shown in Listing 4.1.

Listing 4.1 Transmit Set Up Routine. Channel 0.

```

TXM_ON_0: CLR TXM_START_BIT_0    ; Clear status flag from
                ; previous transmission
          MOV TXM_BUF_0, DATA_0 ; Load "SBUF" with data byte
          MOV TXM_REG_0, TXM_BUF_0
          MOV TXM_COUNT_0, #09    ; 8 data bits + 1 stop bit
          SETB TXM_IN_PROGRESS_0
  
```

270531-9

Listing 4.2 shows the transmit interrupt routine. The first time through, the start bit is transmitted. As each successive interrupt outputs a bit, the contents of TXM\_REG is shifted right one place into the Carry flag, and the TXM\_COUNT is decremented. When TXM\_COUNT equals zero, the stop bit is transmitted.

Listing 4.2. Transmit Interrupt Routine

```

TRANSMIT: PUSH ACC
          PUSH PSW
          CLR CCF3                ; Clear s/w timer interrupt
          ; for transmitting bits
          JNB TXM_IN_PROGRESS_0, TRANSMIT_1 ; Check which
          ; channel is transmitting.
          ; "TRANSMIT_1" is listed in
          ; the Appendix
;
TRANSMIT_0: JB TXM_START_BIT_0, TXM_BYTE_0 ; If start bit
          ; has been sent, continue
          ; transmitting bits.
          CLR P3.2                ; Otherwise transmit start
          ; bit
          SETB TXM_START_BIT_0    ; Signify start bit sent
          JMP TXM_EXIT
;
TXM_BYTE_0: DJNZ TXM_COUNT_0, TXM_DATA_0 ; If bit count
          ; equals 1 thru 9, transmit
          ; data bits (8 total)
;
TXM_STOP_0: SETB P3.2            ; When bit count = 0,
          ; transmit stop bit
          CLR TXM_IN_PROGRESS_0  ; Indicate transmission is
          ; finished and ready for
          ; next byte
          JMP TXM_EXIT
;
TXM_DATA_0: MOV A, TXM_REG_0     ; Transmit one bit at a time
          RRC A                  ; through the carry bit
          MOV P3.2, C
          MOV TXM_REG_0, A      ; Save what's not been sent
;
TXM_EXIT:  CLR C                ; Update compare value with
          MOV A, #FULL_BIT_LOW  ; Full bit time = 22CH
          ADD A, CCAP3L
          MOV CCAP3L, A
          MOV A, #FULL_BIT_HIGH
          ADDC A, CCAP3H
          MOV CCAP3H, A
          POP PSW
          POP ACC
          RETI

```

270531-10

## Conclusion

The software routines in the Appendix can be altered to vary the baud rate and number of channels to fit a particular application. The number of channels which can be implemented is limited by the CPU time required to service the PCA interrupt. At higher baud rates, fewer channels can be run.

The test program verifies the simultaneous operation of three half-duplex channels at 2400 Baud and the on-chip full-duplex channel at 9600 Baud. Thirty-three percent of the CPU time is required to operate all four channels. The test was run for several hours with no apparent malfunctions.



```

MCS-51 MACRO ASSEMBLER      SWF0RT      01/01/80      PAGE      2
LOC OBJ      LINE      SOURCE
0030      199      RCV_BUF_0      DATA
0040      200      RCV_BUF_1      DATA
0050      201      RCV_BUF_2      DATA
0031      202      RCV_REC_0      DATA
0041      203      RCV_REC_1      DATA
0051      204      RCV_REC_2      DATA
0032      205      RCV_COUNT_0      DATA
0042      206      RCV_COUNT_1      DATA
0052      207      RCV_COUNT_2      DATA
0033      208      COUNT_0      DATA
0043      209      COUNT_1      DATA
0053      210      COUNT_2      DATA
0011      211      NEG_EDGE      EQU
0049      212      S_W_TIMER      EQU
0015      213      HALF_BIT_LOW      EQU
0001      214      HALF_BIT_HIGH      EQU
002C      215      FULL_BIT_LOW      EQU
0002      216      FULL_BIT_HIGH      EQU
222      ?
223      ?
224      ?
225      ?
226      ?
227      ?
228      ?
229      ?
230      ?
231      ?
232      ?
233      ?
234      ?
235      ?
236      ?
237      ?
238      ?
239      ?
240      ?
241      ?
242      ?
243      ?
244      ?
245      ?
246      ?
247      ?
248      ?
249      ?
250      ?
251      ?
252      ?
253      ?

0036 75815F      INITIALIZE:      MOV SP, #5FH
0039 75D900      INIT_PCA:      MOV CMO0, #00H
003C 75D800      MOV CC0N, #00H
003F 75DA11      MOV CCAPM0, #NEG_EDGE
0042 75DB11      MOV CCAPM1, #NEG_EDGE
0045 75DC11      MOV CCAPM2, #NEG_EDGE
0048 75E900      MOV CL, #00H
0049 75E900      MOV CH, #00H
004E 75A808      MOV LE, #0D8H
0051 D2DE      SETB CR

0053 759850      INIT_SP:      MOV SCON, #50H
0056 75CBFF      MOV RCAP2H, #0FFH
0059 75CACC      MOV RCAP2L, #0CCH
005C 75C834      MOV TZCON, #34H

005F C200      INIT_FLAGS:   CLR RCV_START_BIT_0
0061 C208      CLR RCV_START_BIT_1
0063 C210      CLR RCV_START_BIT_2
0065 C201      CLR RCV_DONE_0

30H      ; Software receive "SRUF"
40H      DATA
50H      DATA
31H      ; Temporary register for
41H      ; receiving bits
51H      DATA
32H      ; Counter for receiving bits
42H      DATA
52H      DATA
33H      ; Used in test program to check
43H      ; bytes being received
53H      DATA
11H      ; Two modes of operation for the
49H      ; Compare/Capture modules
15H      ; Half bit time = 115H
01H      EQU
2CH      ; Full bit time = 22CH
02H      EQU
; 2400 Baud @ 16MHz

=====
INITIALIZATION ROUTINE
=====
; Initialize stack pointer
; (specific to the test program)
; Clear all status flags
; Module 0 in Neg-edge capture mode (P1.3)
; Module 1 " " " " (P1.4)
; Module 2 " " " " (P1.5)

; Initialize needed interrupt: EA, EC, ES, ET1
; Turn on PCA counter
; Serial port in mode 1 (8-Bit UART)
; Reload values for 9600 Baud @ 16 MHz
; timer 2 as a baud-rate generator,
; turn on timer 2
    
```

MCS-51 MACRO ASSEMBLER SWPORT

```

LOC OBJ          LINE          SOURCE
0067 C209        254          CLR RCV_DONE_1
0069 C211        255          CLR RCV_DONE_2
                256          ;
006B C202        257          CLR RCV_ON_0
006D C20A        258          CLR RCV_ON_1
006F C212        259          CLR RCV_ON_2
                260          ;
                261          ; Port 3 pins used in test program for error routines
                262          ;
                263          ; Main program:
0071 D2B2        264          SETB P3.2          ; Error in comparison on module 0
0073 D2B3        265          SETB P3.3          ; Error in comparison on module 1
0075 D2B4        266          SETB P3.4          ; Error in comparison on module 2
                267          ;
                268          ; Interrupt routines:
0077 D2B5        269          SETB P3.5          ; Error in reception on module 0
0079 D2B6        270          SETB P3.6          ; Error in reception on module 1
007B D2B7        271          SETB P3.7          ; Error in reception on module 2
                272          ;
007D 753000      273          MOV RCV_BUF_0, #00H
0080 754000      274          MOV RCV_BUF_1, #00H
0083 755000      275          MOV RCV_BUF_2, #00H
                276          ;
0086 753200      277          MOV RCV_COUNT_0, #00H
0089 754200      278          MOV RCV_COUNT_1, #00H
008C 755200      279          MOV RCV_COUNT_2, #00H
                280          ;
008F 753100      281          MOV RCV_REG_0, #00H
0092 754100      282          MOV RCV_REG_1, #00H
0095 755100      283          MOV RCV_REG_2, #00H
                284          ;
0098 753300      285          MOV COUNT_0, #00H
009B 754300      286          MOV COUNT_1, #00H
009E 755300      287          MOV COUNT_2, #00H
                288          ;
                289          ;
                290          ;
                291          ;
                292          ;
                293          ;
                294          ;
                295          ;
                296          ;
                297          ;
                298          ;
                299          ;
00A1 300209      300          MAIN TEST ROUTINE - RECEIVE BITS
00A4 E530        301          ; =====
00A6 B5331E      302          ; Main program continually checks
00A9 C202        303          CLR RCV_ON_0      ; each channel for a received byte.
00AB 0533        304          INC COUNT_0      ; Once a byte is received, it is compared
                305          ; with the current value in the "COUNT"
                306          ; register
                307          ;
00AD 300A09      308          JNB RCV_ON_1, CHECK_2
00B0 E540        309          MOV A, RCV_BUF_1
00B2 B54319      310          CJNE A, COUNT_1, ERROR1
00B5 C20A        311          CLR RCV_ON_1
00B7 0543        312          INC COUNT_1
                313          ;
00B9 3012E5      314          JNB RCV_ON_2, CHECK_0
00BB B5431E      315          MOV A, RCV_BUF_2
00BD 0543        316          CJNE A, COUNT_2, ERROR2
00BE B55314      317          INC COUNT_2
                318          ;
                319          ;
                320          ;
                321          ;
                322          ;
                323          ;
                324          ;
                325          ;
                326          ;
                327          ;
                328          ;
                329          ;
                330          ;
                331          ;
                332          ;
                333          ;
                334          ;
                335          ;
                336          ;
                337          ;
                338          ;
                339          ;
                340          ;
                341          ;
                342          ;
                343          ;
                344          ;
                345          ;
                346          ;
                347          ;
                348          ;
                349          ;
                350          ;
                351          ;
                352          ;
                353          ;
                354          ;
                355          ;
                356          ;
                357          ;
                358          ;
                359          ;
                360          ;
                361          ;
                362          ;
                363          ;
                364          ;
                365          ;
                366          ;
                367          ;
                368          ;
                369          ;
                370          ;
                371          ;
                372          ;
                373          ;
                374          ;
                375          ;
                376          ;
                377          ;
                378          ;
                379          ;
                380          ;
                381          ;
                382          ;
                383          ;
                384          ;
                385          ;
                386          ;
                387          ;
                388          ;
                389          ;
                390          ;
                391          ;
                392          ;
                393          ;
                394          ;
                395          ;
                396          ;
                397          ;
                398          ;
                399          ;
                400          ;
                401          ;
                402          ;
                403          ;
                404          ;
                405          ;
                406          ;
                407          ;
                408          ;
                409          ;
                410          ;
                411          ;
                412          ;
                413          ;
                414          ;
                415          ;
                416          ;
                417          ;
                418          ;
                419          ;
                420          ;
                421          ;
                422          ;
                423          ;
                424          ;
                425          ;
                426          ;
                427          ;
                428          ;
                429          ;
                430          ;
                431          ;
                432          ;
                433          ;
                434          ;
                435          ;
                436          ;
                437          ;
                438          ;
                439          ;
                440          ;
                441          ;
                442          ;
                443          ;
                444          ;
                445          ;
                446          ;
                447          ;
                448          ;
                449          ;
                450          ;
                451          ;
                452          ;
                453          ;
                454          ;
                455          ;
                456          ;
                457          ;
                458          ;
                459          ;
                460          ;
                461          ;
                462          ;
                463          ;
                464          ;
                465          ;
                466          ;
                467          ;
                468          ;
                469          ;
                470          ;
                471          ;
                472          ;
                473          ;
                474          ;
                475          ;
                476          ;
                477          ;
                478          ;
                479          ;
                480          ;
                481          ;
                482          ;
                483          ;
                484          ;
                485          ;
                486          ;
                487          ;
                488          ;
                489          ;
                490          ;
                491          ;
                492          ;
                493          ;
                494          ;
                495          ;
                496          ;
                497          ;
                498          ;
                499          ;
                500          ;
                501          ;
                502          ;
                503          ;
                504          ;
                505          ;
                506          ;
                507          ;
                508          ;
                509          ;
                510          ;
                511          ;
                512          ;
                513          ;
                514          ;
                515          ;
                516          ;
                517          ;
                518          ;
                519          ;
                520          ;
                521          ;
                522          ;
                523          ;
                524          ;
                525          ;
                526          ;
                527          ;
                528          ;
                529          ;
                530          ;
                531          ;
                532          ;
                533          ;
                534          ;
                535          ;
                536          ;
                537          ;
                538          ;
                539          ;
                540          ;
                541          ;
                542          ;
                543          ;
                544          ;
                545          ;
                546          ;
                547          ;
                548          ;
                549          ;
                550          ;
                551          ;
                552          ;
                553          ;
                554          ;
                555          ;
                556          ;
                557          ;
                558          ;
                559          ;
                560          ;
                561          ;
                562          ;
                563          ;
                564          ;
                565          ;
                566          ;
                567          ;
                568          ;
                569          ;
                570          ;
                571          ;
                572          ;
                573          ;
                574          ;
                575          ;
                576          ;
                577          ;
                578          ;
                579          ;
                580          ;
                581          ;
                582          ;
                583          ;
                584          ;
                585          ;
                586          ;
                587          ;
                588          ;
                589          ;
                590          ;
                591          ;
                592          ;
                593          ;
                594          ;
                595          ;
                596          ;
                597          ;
                598          ;
                599          ;
                600          ;
                601          ;
                602          ;
                603          ;
                604          ;
                605          ;
                606          ;
                607          ;
                608          ;
                609          ;
                610          ;
                611          ;
                612          ;
                613          ;
                614          ;
                615          ;
                616          ;
                617          ;
                618          ;
                619          ;
                620          ;
                621          ;
                622          ;
                623          ;
                624          ;
                625          ;
                626          ;
                627          ;
                628          ;
                629          ;
                630          ;
                631          ;
                632          ;
                633          ;
                634          ;
                635          ;
                636          ;
                637          ;
                638          ;
                639          ;
                640          ;
                641          ;
                642          ;
                643          ;
                644          ;
                645          ;
                646          ;
                647          ;
                648          ;
                649          ;
                650          ;
                651          ;
                652          ;
                653          ;
                654          ;
                655          ;
                656          ;
                657          ;
                658          ;
                659          ;
                660          ;
                661          ;
                662          ;
                663          ;
                664          ;
                665          ;
                666          ;
                667          ;
                668          ;
                669          ;
                670          ;
                671          ;
                672          ;
                673          ;
                674          ;
                675          ;
                676          ;
                677          ;
                678          ;
                679          ;
                680          ;
                681          ;
                682          ;
                683          ;
                684          ;
                685          ;
                686          ;
                687          ;
                688          ;
                689          ;
                690          ;
                691          ;
                692          ;
                693          ;
                694          ;
                695          ;
                696          ;
                697          ;
                698          ;
                699          ;
                700          ;
                701          ;
                702          ;
                703          ;
                704          ;
                705          ;
                706          ;
                707          ;
                708          ;
                709          ;
                710          ;
                711          ;
                712          ;
                713          ;
                714          ;
                715          ;
                716          ;
                717          ;
                718          ;
                719          ;
                720          ;
                721          ;
                722          ;
                723          ;
                724          ;
                725          ;
                726          ;
                727          ;
                728          ;
                729          ;
                730          ;
                731          ;
                732          ;
                733          ;
                734          ;
                735          ;
                736          ;
                737          ;
                738          ;
                739          ;
                740          ;
                741          ;
                742          ;
                743          ;
                744          ;
                745          ;
                746          ;
                747          ;
                748          ;
                749          ;
                750          ;
                751          ;
                752          ;
                753          ;
                754          ;
                755          ;
                756          ;
                757          ;
                758          ;
                759          ;
                760          ;
                761          ;
                762          ;
                763          ;
                764          ;
                765          ;
                766          ;
                767          ;
                768          ;
                769          ;
                770          ;
                771          ;
                772          ;
                773          ;
                774          ;
                775          ;
                776          ;
                777          ;
                778          ;
                779          ;
                780          ;
                781          ;
                782          ;
                783          ;
                784          ;
                785          ;
                786          ;
                787          ;
                788          ;
                789          ;
                790          ;
                791          ;
                792          ;
                793          ;
                794          ;
                795          ;
                796          ;
                797          ;
                798          ;
                799          ;
                800          ;
                801          ;
                802          ;
                803          ;
                804          ;
                805          ;
                806          ;
                807          ;
                808          ;
                809          ;
                810          ;
                811          ;
                812          ;
                813          ;
                814          ;
                815          ;
                816          ;
                817          ;
                818          ;
                819          ;
                820          ;
                821          ;
                822          ;
                823          ;
                824          ;
                825          ;
                826          ;
                827          ;
                828          ;
                829          ;
                830          ;
                831          ;
                832          ;
                833          ;
                834          ;
                835          ;
                836          ;
                837          ;
                838          ;
                839          ;
                840          ;
                841          ;
                842          ;
                843          ;
                844          ;
                845          ;
                846          ;
                847          ;
                848          ;
                849          ;
                850          ;
                851          ;
                852          ;
                853          ;
                854          ;
                855          ;
                856          ;
                857          ;
                858          ;
                859          ;
                860          ;
                861          ;
                862          ;
                863          ;
                864          ;
                865          ;
                866          ;
                867          ;
                868          ;
                869          ;
                870          ;
                871          ;
                872          ;
                873          ;
                874          ;
                875          ;
                876          ;
                877          ;
                878          ;
                879          ;
                880          ;
                881          ;
                882          ;
                883          ;
                884          ;
                885          ;
                886          ;
                887          ;
                888          ;
                889          ;
                890          ;
                891          ;
                892          ;
                893          ;
                894          ;
                895          ;
                896          ;
                897          ;
                898          ;
                899          ;
                900          ;
                901          ;
                902          ;
                903          ;
                904          ;
                905          ;
                906          ;
                907          ;
                908          ;
                909          ;
                910          ;
                911          ;
                912          ;
                913          ;
                914          ;
                915          ;
                916          ;
                917          ;
                918          ;
                919          ;
                920          ;
                921          ;
                922          ;
                923          ;
                924          ;
                925          ;
                926          ;
                927          ;
                928          ;
                929          ;
                930          ;
                931          ;
                932          ;
                933          ;
                934          ;
                935          ;
                936          ;
                937          ;
                938          ;
                939          ;
                940          ;
                941          ;
                942          ;
                943          ;
                944          ;
                945          ;
                946          ;
                947          ;
                948          ;
                949          ;
                950          ;
                951          ;
                952          ;
                953          ;
                954          ;
                955          ;
                956          ;
                957          ;
                958          ;
                959          ;
                960          ;
                961          ;
                962          ;
                963          ;
                964          ;
                965          ;
                966          ;
                967          ;
                968          ;
                969          ;
                970          ;
                971          ;
                972          ;
                973          ;
                974          ;
                975          ;
                976          ;
                977          ;
                978          ;
                979          ;
                980          ;
                981          ;
                982          ;
                983          ;
                984          ;
                985          ;
                986          ;
                987          ;
                988          ;
                989          ;
                990          ;
                991          ;
                992          ;
                993          ;
                994          ;
                995          ;
                996          ;
                997          ;
                998          ;
                999          ;
                1000         ;

```

LOC	OBJ	MCS-51 MACRO ASSEMBLER	SWPORT	LINE	SOURCE
			01/01/80	PAGE	4
309					CLR RCV_ON_2
310	00C1 C212				INC COUNT_2
311	00C3 0553				JMP CHECK_0
312	00C5 80DA				
313	00C7 C2B2				; Error in comparison on module 0
314	00C9 75DA00				; Discontinue receiving bytes
315	00CC 80DF				
316					CLR P3.2
317	00CE C2B3				MOV CCAPM0_1, #00H
318	00D0 75DB00				
319	00D3 80E4				CLR P3.3
320					MOV CCAPM1, #00H
321	00D5 C2B4				CLR P3.4
322	00D7 75DC00				MOV CCAPM2, #00H
323	00DA 80C5				JMP CHECK_0
324					
325					
326					
327					
328					PCA INTERRUPT ROUTINE - RECEIVE BITS
329					=====
330	00DC C0E0				PUSH ACC
331	00DE C0D0				PUSH PSW
332					
333	00E0 20D811				JB CCF0, MODULE_0
334	00E3 20D808				; Check which module caused
335	00E6 20DA08				; PCA interrupt and jump to
336	00E9 D0D0				; appropriate routine
337	00EB 80E0				POP PSW
338	00ED 32				POP ACC
339					RET
340	00EE 0201E4				LJMP MODULE_1
341	00F1 0201E4				LJMP MODULE_2
342					
343					
344					
345					CHANNEL_0
346					=====
347					
348	00F4 C2D8				CLR CCF0
349	00F6 E5DA				MOV A, CCAPM0
350	00F8 547F				ANL A, #01111111B
351	00FA B41115				CJNE A, #NEG_EDGE, RCV_START_0
352					; Reception on module 0
353					; Check mode of module. If set up to
354					; receive negative edges, then module
355					; is waiting for a start bit
356					
357					CLR C
358					MOV A, #HALF_BIT_LOW
359					ADD A, CCAP0L
360					MOV CCAP0L, A
361					MOV A, #HALF_BIT_HIGH
362					ADD A, CCAP0H
363					MOV CCAP0H, A
364					MOV CCAPM0, #S_H_TIMER
365					POP PSW
366					POP ACC



MCS-51 MACRO ASSEMBLER	SWF0RT	SOURCE	LINE
LOC OBJ			
0111 32		RETI	364
0112 B4494B		CJNE A, #S_M_TIMER, ERROR_0	365
0115 20001A	RCV_START_0:	JB RCV_START_BIT_0, RCV_BYTE_0	366
0118 209345		JB P1.3, ERROR_0	367
011B D200		SETB RCV_START_BIT_0	368
011D 753209		MOV RCV_COUNT_0, #09H	369
0120 C3		CLR C	370
0121 742C		MOV C, #FULL_BIT_LOW	371
0123 25FA		ADD A, CCAPOH	372
0125 F5EA		MOV CCAPOH, A	373
0127 7402		MOV A, #FULL_BIT_HIGH	374
0129 35FA		ADDC A, CCAPOH	375
012B F3FA		MOV CCAPOH, A	376
012D 0BE0		POP PSW	377
012F 0BE0		POP ACC	378
0131 32		RETI	379
0132 D53212	RCV_BYTE_0:	DJNZ RCV_COUNT_0, RCV_DATA_0	380
0135 309328	RCV_STOP_0:	JNB P1.3, ERROR_0	381
0138 D3130		SETB RCV_DONE_0	382
013D D28F		SETB TFI	383
013F 75D411		MOV CCAPMO, #NEG_EDGE	384
0142 D4D0		POP PSW	385
0144 0BE0		POP ACC	386
0146 32		RETI	387
0147 A293	RCV_DATA_0:	MOV C, P1.3	388
0149 E831		MOV A, RCV_REG_0	389
014B 13		RRC A	390
014C F531		MOV RCV_REG_0, A	391
014E C3		CLR C	392
0151 742C		MOV C, #FULL_BIT_LOW	393
0153 F5EA		ADD A, CCAPOH	394
0155 7402		MOV A, #FULL_BIT_HIGH	395
0157 35FA		ADDC A, CCAPOH	396
0159 F3FA		MOV CCAPOH, A	397
015B D4D0		POP PSW	398
015D 0BE0		POP ACC	399
015F 32		RETI	400
0160 C2B5	ERROR_0:	CLR P3.5	401
			402
			403
			404
			405
			406
			407
			408
			409
			410
			411
			412
			413
			414
			415
			416
			417

MCS-51 MACRO ASSEMBLER	SWPORT	LINE	SOURCE
		418	
		419	
0162 75DA11		420	
0165 C200		421	
0167 D0D0		422	
0169 D0E0		423	
016B 32		424	
		425	
		426	
		427	
		428	
016C C2D9		429	
016E E5DB		430	
0170 547F		431	
0172 B41115		432	
		433	
		434	
0175 C3		435	
0176 7415		436	
0178 25EB		437	
017A F5BB		438	
017C 7401		439	
017E F5EB		440	
0180 7402		441	
0182 75DB49		442	
0185 D0D0		443	
0187 D0E0		444	
0189 32		445	
018A B4494B		446	
018C 2081		447	
0190 209445		448	
		449	
0193 D208		450	
0195 754209		451	
		452	
0198 C3		453	
0199 242C		454	
019B 25EB		455	
019D F5EB		456	
019F 7402		457	
01A1 35FB		458	
01A3 F5FB		459	
01A5 D0D0		460	
01A7 D0E0		461	
01A9 32		462	
		463	
01AA D54212		464	
		465	
01AD 309428		466	
01B0 854140		467	
01B3 D209		468	
01B7 740E		469	
01B9 740E		470	
01BA D0D0		471	
01BC D0E0		472	

```

NCS-51 MACRO ASSEMBLER      SWF0RT
LOC OBJ      LINE      SOURCE
01BE 32      473      RETI
01BF A294    474      MOV C, P1.4
01C0 E541    475      MOV A, RCV_REG_1
01C1 13      476      RRC A
01C2 13      477      MOV RCV_REG_1, A
01C3 13      478      ;
01C4 F541    479      ;
01C5 C3      480      CLR C
01C6 742C    481      MOV A, #FULL_BIT_LOW
01C7 25EB    482      ADD A, CCAP1L
01C8 F5EB    483      MOV CCAP1L, A
01C9 7402    484      MOV A, #FULL_BIT_HIGH
01CA 35FB    485      ADDC A, CCAP1H
01CB F5FB    486      MOV CCAP1H, A
01CC D0D0    487      POP FSN
01CD 09E0    488      POP ACC
01CE 32      489      RETI
01CF 32      490      ;
01D0 C2B6    491      CLR P3.6
01D1 75DB11  492      MOV CCAP1L, #NEG_EDGE
01D2 C208    493      CLR RCV_START_BIT_1
01D3 D0D0    494      POP FSN
01D4 D0D0    495      POP ACC
01D5 32      496      RETI
01D6 32      497      ;
01D7 32      498      ;
01D8 32      499      ;
01D9 32      500      ;
01DA 32      501      ;
01DB 32      502      ;
01DC 32      503      ;
01DD 32      504      ;
01DE 32      505      ;
01DF 32      506      ;
01E0 32      507      ;
01E1 32      508      ;
01E2 32      509      ;
01E3 32      510      ;
01E4 C2DA    511      CLR CCF2
01E5 E5DC    512      MOV A, CCAP2M
01E6 547F    513      ANL A, #01111111B
01E7 B41115  514      CJNE A, #NEG_EDGE, RCV_START_2
01E8 32      515      ;
01E9 32      516      ;
01EA 32      517      ;
01EB 32      518      ;
01EC 32      519      ;
01ED 32      520      ;
01EE 32      521      ;
01EF 32      522      ;
01F0 32      523      ;
01F1 32      524      ;
01F2 32      525      ;
01F3 32      526      ;
01F4 32      527      ;
01F5 32      528      ;
01F6 32      529      ;
01F7 32      530      ;
01F8 32      531      ;
01F9 32      532      ;
01FA 32      533      ;
01FB 32      534      ;
01FC 32      535      ;
01FD 32      536      ;
01FE 32      537      ;
01FF 32      538      ;
0200 32      539      ;
0201 32      540      ;
0202 B4494B  541      CLR RCV_START_BIT_2
0203 20101A  542      JB P1.5, ERROR_2
0204 203545  543      ;
0205 32      544      ;
0206 32      545      ;
0207 32      546      ;
0208 32      547      ;
0209 32      548      ;
020A 32      549      ;
020B 32      550      ;
020C 32      551      ;
020D 32      552      ;
020E 32      553      ;
020F 32      554      ;
0210 32      555      ;
0211 32      556      ;
0212 32      557      ;
0213 32      558      ;
0214 32      559      ;
0215 32      560      ;
0216 32      561      ;
0217 32      562      ;
0218 32      563      ;
0219 32      564      ;
021A 32      565      ;
021B 32      566      ;
021C 32      567      ;
021D 32      568      ;
021E 32      569      ;
021F 32      570      ;
0220 32      571      ;
0221 32      572      ;
0222 32      573      ;
0223 32      574      ;
0224 32      575      ;
0225 32      576      ;
0226 32      577      ;
0227 32      578      ;
0228 32      579      ;
0229 32      580      ;
022A 32      581      ;
022B 32      582      ;
022C 32      583      ;
022D 32      584      ;
022E 32      585      ;
022F 32      586      ;
0230 32      587      ;
0231 32      588      ;
0232 32      589      ;
0233 32      590      ;
0234 32      591      ;
0235 32      592      ;
0236 32      593      ;
0237 32      594      ;
0238 32      595      ;
0239 32      596      ;
023A 32      597      ;
023B 32      598      ;
023C 32      599      ;
023D 32      600      ;
023E 32      601      ;
023F 32      602      ;
0240 32      603      ;
0241 32      604      ;
0242 32      605      ;
0243 32      606      ;
0244 32      607      ;
0245 32      608      ;
0246 32      609      ;
0247 32      610      ;
0248 32      611      ;
0249 32      612      ;
024A 32      613      ;
024B 32      614      ;
024C 32      615      ;
024D 32      616      ;
024E 32      617      ;
024F 32      618      ;
0250 32      619      ;
0251 32      620      ;
0252 32      621      ;
0253 32      622      ;
0254 32      623      ;
0255 32      624      ;
0256 32      625      ;
0257 32      626      ;
0258 32      627      ;
0259 32      628      ;
025A 32      629      ;
025B 32      630      ;
025C 32      631      ;
025D 32      632      ;
025E 32      633      ;
025F 32      634      ;
0260 32      635      ;
0261 32      636      ;
0262 32      637      ;
0263 32      638      ;
0264 32      639      ;
0265 32      640      ;
0266 32      641      ;
0267 32      642      ;
0268 32      643      ;
0269 32      644      ;
026A 32      645      ;
026B 32      646      ;
026C 32      647      ;
026D 32      648      ;
026E 32      649      ;
026F 32      650      ;
0270 32      651      ;
0271 32      652      ;
0272 32      653      ;
0273 32      654      ;
0274 32      655      ;
0275 32      656      ;
0276 32      657      ;
0277 32      658      ;
0278 32      659      ;
0279 32      660      ;
027A 32      661      ;
027B 32      662      ;
027C 32      663      ;
027D 32      664      ;
027E 32      665      ;
027F 32      666      ;
0280 32      667      ;
0281 32      668      ;
0282 32      669      ;
0283 32      670      ;
0284 32      671      ;
0285 32      672      ;
0286 32      673      ;
0287 32      674      ;
0288 32      675      ;
0289 32      676      ;
028A 32      677      ;
028B 32      678      ;
028C 32      679      ;
028D 32      680      ;
028E 32      681      ;
028F 32      682      ;
0290 32      683      ;
0291 32      684      ;
0292 32      685      ;
0293 32      686      ;
0294 32      687      ;
0295 32      688      ;
0296 32      689      ;
0297 32      690      ;
0298 32      691      ;
0299 32      692      ;
029A 32      693      ;
029B 32      694      ;
029C 32      695      ;
029D 32      696      ;
029E 32      697      ;
029F 32      698      ;
02A0 32      699      ;
02A1 32      700      ;
02A2 32      701      ;
02A3 32      702      ;
02A4 32      703      ;
02A5 32      704      ;
02A6 32      705      ;
02A7 32      706      ;
02A8 32      707      ;
02A9 32      708      ;
02AA 32      709      ;
02AB 32      710      ;
02AC 32      711      ;
02AD 32      712      ;
02AE 32      713      ;
02AF 32      714      ;
02B0 32      715      ;
02B1 32      716      ;
02B2 32      717      ;
02B3 32      718      ;
02B4 32      719      ;
02B5 32      720      ;
02B6 32      721      ;
02B7 32      722      ;
02B8 32      723      ;
02B9 32      724      ;
02BA 32      725      ;
02BB 32      726      ;
02BC 32      727      ;
02BD 32      728      ;
02BE 32      729      ;
02BF 32      730      ;
02C0 32      731      ;
02C1 32      732      ;
02C2 32      733      ;
02C3 32      734      ;
02C4 32      735      ;
02C5 32      736      ;
02C6 32      737      ;
02C7 32      738      ;
02C8 32      739      ;
02C9 32      740      ;
02CA 32      741      ;
02CB 32      742      ;
02CC 32      743      ;
02CD 32      744      ;
02CE 32      745      ;
02CF 32      746      ;
02D0 32      747      ;
02D1 32      748      ;
02D2 32      749      ;
02D3 32      750      ;
02D4 32      751      ;
02D5 32      752      ;
02D6 32      753      ;
02D7 32      754      ;
02D8 32      755      ;
02D9 32      756      ;
02DA 32      757      ;
02DB 32      758      ;
02DC 32      759      ;
02DD 32      760      ;
02DE 32      761      ;
02DF 32      762      ;
02E0 32      763      ;
02E1 32      764      ;
02E2 32      765      ;
02E3 32      766      ;
02E4 32      767      ;
02E5 32      768      ;
02E6 32      769      ;
02E7 32      770      ;
02E8 32      771      ;
02E9 32      772      ;
02EA 32      773      ;
02EB 32      774      ;
02EC 32      775      ;
02ED 32      776      ;
02EE 32      777      ;
02EF 32      778      ;
02F0 32      779      ;
02F1 32      780      ;
02F2 32      781      ;
02F3 32      782      ;
02F4 32      783      ;
02F5 32      784      ;
02F6 32      785      ;
02F7 32      786      ;
02F8 32      787      ;
02F9 32      788      ;
02FA 32      789      ;
02FB 32      790      ;
02FC 32      791      ;
02FD 32      792      ;
02FE 32      793      ;
02FF 32      794      ;
0300 32      795      ;
0301 32      796      ;
0302 32      797      ;
0303 32      798      ;
0304 32      799      ;
0305 32      800      ;
0306 32      801      ;
0307 32      802      ;
0308 32      803      ;
0309 32      804      ;
030A 32      805      ;
030B 32      806      ;
030C 32      807      ;
030D 32      808      ;
030E 32      809      ;
030F 32      810      ;
0310 32      811      ;
0311 32      812      ;
0312 32      813      ;
0313 32      814      ;
0314 32      815      ;
0315 32      816      ;
0316 32      817      ;
0317 32      818      ;
0318 32      819      ;
0319 32      820      ;
031A 32      821      ;
031B 32      822      ;
031C 32      823      ;
031D 32      824      ;
031E 32      825      ;
031F 32      826      ;
0320 32      827      ;
0321 32      828      ;
0322 32      829      ;
0323 32      830      ;
0324 32      831      ;
0325 32      832      ;
0326 32      833      ;
0327 32      834      ;
0328 32      835      ;
0329 32      836      ;
032A 32      837      ;
032B 32      838      ;
032C 32      839      ;
032D 32      840      ;
032E 32      841      ;
032F 32      842      ;
0330 32      843      ;
0331 32      844      ;
0332 32      845      ;
0333 32      846      ;
0334 32      847      ;
0335 32      848      ;
0336 32      849      ;
0337 32      850      ;
0338 32      851      ;
0339 32      852      ;
033A 32      853      ;
033B 32      854      ;
033C 32      855      ;
033D 32      856      ;
033E 32      857      ;
033F 32      858      ;
0340 32      859      ;
0341 32      860      ;
0342 32      861      ;
0343 32      862      ;
0344 32      863      ;
0345 32      864      ;
0346 32      865      ;
0347 32      866      ;
0348 32      867      ;
0349 32      868      ;
034A 32      869      ;
034B 32      870      ;
034C 32      871      ;
034D 32      872      ;
034E 32      873      ;
034F 32      874      ;
0350 32      875      ;
0351 32      876      ;
0352 32      877      ;
0353 32      878      ;
0354 32      879      ;
0355 32      880      ;
0356 32      881      ;
0357 32      882      ;
0358 32      883      ;
0359 32      884      ;
035A 32      885      ;
035B 32      886      ;
035C 32      887      ;
035D 32      888      ;
035E 32      889      ;
035F 32      890      ;
0360 32      891      ;
0361 32      892      ;
0362 32      893      ;
0363 32      894      ;
0364 32      895      ;
0365 32      896      ;
0366 32      897      ;
0367 32      898      ;
0368 32      899      ;
0369 32      900      ;
036A 32      901      ;
036B 32      902      ;
036C 32      903      ;
036D 32      904      ;
036E 32      905      ;
036F 32      906      ;
0370 32      907      ;
0371 32      908      ;
0372 32      909      ;
0373 32      910      ;
0374 32      911      ;
0375 32      912      ;
0376 32      913      ;
0377 32      914      ;
0378 32      915      ;
0379 32      916      ;
037A 32      917      ;
037B 32      918      ;
037C 32      919      ;
037D 32      920      ;
037E 32      921      ;
037F 32      922      ;
0380 32      923      ;
0381 32      924      ;
0382 32      925      ;
0383 32      926      ;
0384 32      927      ;
0385 32      928      ;
0386 32      929      ;
0387 32      930      ;
0388 32      931      ;
0389 32      932      ;
038A 32      933      ;
038B 32      934      ;
038C 32      935      ;
038D 32      936      ;
038E 32      937      ;
038F 32      938      ;
0390 32      939      ;
0391 32      940      ;
0392 32      941      ;
0393 32      942      ;
0394 32      943      ;
0395 32      944      ;
0396 32      945      ;
0397 32      946      ;
0398 32      947      ;
0399 32      948      ;
039A 32      949      ;
039B 32      950      ;
039C 32      951      ;
039D 32      952      ;
039E 32      953      ;
039F 32      954      ;
03A0 32      955      ;
03A1 32      956      ;
03A2 32      957      ;
03A3 32      958      ;
03A4 32      959      ;
03A5 32      960      ;
03A6 32      961      ;
03A7 32      962      ;
03A8 32      963      ;
03A9 32      964      ;
03AA 32      965      ;
03AB 32      966      ;
03AC 32      967      ;
03AD 32      968      ;
03AE 32      969      ;
03AF 32      970      ;
03B0 32      971      ;
03B1 32      972      ;
03B2 32      973      ;
03B3 32      974      ;
03B4 32      975      ;
03B5 32      976      ;
03B6 32      977      ;
03B7 32      978      ;
03B8 32      979      ;
03B9 32      980      ;
03BA 32      981      ;
03BB 32      982      ;
03BC 32      983      ;
03BD 32      984      ;
03BE 32      985      ;
03BF 32      986      ;
03C0 32      987      ;
03C1 32      988      ;
03C2 32      989      ;
03C3 32      990      ;
03C4 32      991      ;
03C5 32      992      ;
03C6 32      993      ;
03C7 32      994      ;
03C8 32      995      ;
03C9 32      996      ;
03CA 32      997      ;
03CB 32      998      ;
03CC 32      999      ;
03CD 32      1000     ;

```

MCS-51 MACRO ASSEMBLER SWPORT

LOC	OBJ	LINE	SOURCE
0210	C3	528	CLR C, #FULL_BIT_LOW
0211	742C	529	MOV A, CCAPZL
0213	256C	530	ADD A, CCAPZL
0215	F5EC	531	MOV A, CCAPZL
0217	7402	532	ADD A, #FULL_BIT_HIGH
0219	35FC	533	MOV A, CCAPZL
021B	556C	534	ADD A, CCAPZL
021D	D0E0	535	POP PSW
021F	D0E0	536	POP PSW
0221	32	537	POP ACC
0221	32	538	RETI
0222	D55212	539	DJMZ RCV_COUNT_2, RCV_DATA_2
025	399528	540	JNB P1_5_ERROR_2
026	D31150	541	CLR C
028	D31150	542	SETB RCV_DONE_2, RCV_REG_2
02D	D28F	543	SETB TF1_DONE_2, RCV_REG_2
02E	D28F	544	SETB TF1_DONE_2, RCV_REG_2
02F	75DC11	545	MOV CCAPM2, #NEG_EDGE
0232	D0D0	546	POP PSW
0234	D0E0	547	POP PSW
0236	32	548	RETI
0237	2995	549	MOV C, P1_5
0239	F551	550	MOV A, RCV_REG_2
023B	13	551	RRC A
023C	F551	552	MOV RCV_REG_2, A
023E	C3	553	CLR C
023F	742C	554	MOV A, #FULL_BIT_LOW
0241	256C	555	MOV A, CCAPZL
0243	4	556	ADD A, CCAPZL
0245	7402	557	MOV A, #FULL_BIT_HIGH
0247	35FC	558	MOV A, CCAPZL
0249	F5FC	559	ADD A, CCAPZL
024B	D0D0	560	POP PSW
024D	D0E0	561	POP PSW
024F	32	562	RETI
0250	C2B7	563	CLR P3_7
0252	75DC11	564	MOV CCAPM2, #NEG_EDGE
0255	C210	565	CLR RCV_START_BIT_2
0257	D0D0	566	POP PSW
0259	D0E0	567	POP PSW
025B	32	568	POP ACC
025D	7777	569	RETI
025F	7777	570	RETI
0261	7777	571	RETI
0263	7777	572	RETI
0265	7777	573	RETI
0267	7777	574	RETI
0269	7777	575	RETI
026B	7777	576	RETI
026D	7777	577	RETI
026F	7777	578	RETI
0271	7777	579	RETI
0273	7777	580	RETI
0275	7777	581	RETI
0277	7777	582	RETI
0279	7777	583	RETI
027B	7777	584	RETI
027D	7777	585	RETI
027F	7777	586	RETI
0281	7777	587	RETI
0283	7777	588	RETI
0285	7777	589	RETI
0287	7777	590	RETI
0289	7777	591	RETI
028B	7777	592	RETI
028D	7777	593	RETI
028F	7777	594	RETI
0291	7777	595	RETI
0293	7777	596	RETI
0295	7777	597	RETI
0297	7777	598	RETI
0299	7777	599	RETI
029B	7777	600	RETI
029D	7777	601	RETI
029F	7777	602	RETI
02A1	7777	603	RETI
02A3	7777	604	RETI
02A5	7777	605	RETI
02A7	7777	606	RETI
02A9	7777	607	RETI
02AB	7777	608	RETI
02AD	7777	609	RETI
02AF	7777	610	RETI
02B1	7777	611	RETI
02B3	7777	612	RETI
02B5	7777	613	RETI
02B7	7777	614	RETI
02B9	7777	615	RETI
02BB	7777	616	RETI
02BD	7777	617	RETI
02BF	7777	618	RETI
02C1	7777	619	RETI
02C3	7777	620	RETI
02C5	7777	621	RETI
02C7	7777	622	RETI
02C9	7777	623	RETI
02CB	7777	624	RETI
02CD	7777	625	RETI
02CF	7777	626	RETI
02D1	7777	627	RETI
02D3	7777	628	RETI
02D5	7777	629	RETI
02D7	7777	630	RETI
02D9	7777	631	RETI
02DB	7777	632	RETI
02DD	7777	633	RETI
02DF	7777	634	RETI
02E1	7777	635	RETI
02E3	7777	636	RETI
02E5	7777	637	RETI
02E7	7777	638	RETI
02E9	7777	639	RETI
02EB	7777	640	RETI
02ED	7777	641	RETI
02EF	7777	642	RETI
02F1	7777	643	RETI
02F3	7777	644	RETI
02F5	7777	645	RETI
02F7	7777	646	RETI
02F9	7777	647	RETI
02FB	7777	648	RETI
02FD	7777	649	RETI
02FF	7777	650	RETI

; This routine simulates the "RI" interrupt. When a byte is received on one  
; of the channels, this interrupt is generated. Bits are set so the main  
; routine knows which channel received a byte.

RECEIVE\_DONE: PUSH ACC  
PUSH PSW  
CLR TF1

MCS-51 MACRO ASSEMBLER SWFPORT

```

LOC OBJ          LINE          SOURCE
0262 300106      583          JNB RCV_DONE_0, RCV_1 ; Check which module received a byte
0265 C201        584          CLR RCV_DONE_0 ; Clear flags needed for next reception
0267 C200        585          SETB RCV_ON_0 ; Tell main routine which channel received
0269 D202,      586          ; a byte
026B 300306      587          JNB RCV_DONE_1, RCV_2
026E C209        588          CLR RCV_DONE_1
0270 C208        589          CLR RCV_START_BIT_1
0272 D20A,      590          SETB RCV_ON_1
0274 301106      591          ; RCV_2:
0277 C211        592          JNB RCV_DONE_2, RETURN
0279 C210        593          CLR RCV_DONE_2
027B D212,      594          CLR RCV_START_BIT_2
027D D0D0        595          SETB RCV_ON_2
027F D0E0        596          ; RETURN:
0281 32          597          POP PSW
0282 C0E0        598          POP ACC
0284 C0D0        599          RETI
0286 30980B      600          ;
0288 E359        601          ;
028A F459        602          ;
028C F459        603          ;
028E F459        604          ;
0290 F459        605          ;
0292 F459        606          ;
0294 F459        607          ;
0296 F459        608          ; When a byte is received on the full-duplex serial port, it is then
0298 F459        609          ; transmitted back to a "dummy" terminal. This terminal checks that the
029A F459        610          ; byte it transmitted to the PCA is the same value it receives back.
029C F459        611          ;
029E F459        612          ;
02A0 F459        613          ; SERIAL_PORT:
02A2 C0E0        614          PUSH ACC
02A4 C0D0        615          PUSH PSW
02A6 30980B      616          JNB RI, TXM ; Check whether RI or TI
02A8 E359        617          MOV A, SBUF ; caused the interrupt
02AA F459        618          MOV SBUF, A
02AC F459        619          POP PSW, A
02AE D0D0        620          POP ACC
02B0 D0E0        621          RETI
02B2 C0E0        622          ;
02B4 C299        623          CLR TI
02B6 D0D0        624          POP PSW
02B8 D0E0        625          POP ACC
02BA 32          626          RETI
02BC 32          627          ;
02BE 32          628          ; END

```

REGISTER BANK(S) USED: 0  
ASSEMBLY COMPLETE, NO ERRORS FOUND

MCS-51 MACRO ASSEMBLER SWP0RT  
 DOS 3.20 (038-N) MCS-51 MACRO ASSEMBLER, V2.2  
 OBJECT MODULE PLACED IN SWP0RT.OBJ  
 ASSEMBLER INVOKED BY: C:\AEDIT\ASMS1.EXE SWP0RT.TR

LOC	OBJ	LINE	SOURCE
		1	\$NOMOD51
		2	\$NSYMBOLS
		3	\$NOLIST
		152	;
		153	;
		154	;
		155	;
		156	;
		157	;
		158	;
		159	;
		160	;
		161	;
		162	;
		163	;
		164	ORG 00H
0000		165	LAMP INIT_TXM
0000	020036	166	;
0023		167	ORG 0023H
0023	02014B	168	LAMP SERIAL_PORT
		169	;
0033		170	ORG 0033H
0033	0200D0	171	LAMP TRANSMIT
		172	;
		173	;
		174	;
		175	;
		176	;
		177	TXM START_BIT_0
0003		177	TXM_START_BIT_1
000B		178	TXM_START_BIT_2
0013		179	TXM_START_BIT_3
		180	TXM_IN_PROGRESS_0
0004		181	TXM_IN_PROGRESS_1
000C		182	TXM_IN_PROGRESS_2
0014		183	TXM_BUF_0
0034		185	TXM_BUF_1
0044		186	TXM_BUF_2
0054		187	TXM_BUF_3
		188	TXM_REG_0
0035		189	TXM_REG_1
0045		190	TXM_REG_2
0055		191	TXM_REG_3
		192	TXM_COUNT_0
0036		193	TXM_COUNT_1
0046		194	TXM_COUNT_2
0056		195	TXM_COUNT_3
		196	DATA_0
0037		197	DATA_1
0047		198	DATA_2

```

LOC OBJ          LINE   SOURCE
0057             199   DATA_2
0049             200   EQU          5_W_TIMER
002C             202   EQU          FULL_BIT_LOW
0002             203   EQU          FULL_BIT_HIGH
0002             204   EQU          2CH
0002             205   EQU          02H
0036 75815F      206   ; Software timer mode for the
0039 75D900      207   ; compare/capture module
003C 75D800      208   ; Full bit time = 22CH
003F 75F900      209   ; 2400 Baud at 16 Mhz
0042 75E900      210   ;
0045 75DD49      211   ;
0048 75A8D8      212   ;
004B 759850      213   ;
004E 75C8FE      214   ;
0051 75C8CC      215   ;
0054 75C834      216   ;
0057 C203        217   ;
0059 C20B        218   ;
005B C213        219   ;
005D C204        220   ;
005F C20C        221   ;
0061 C214        222   ;
0063 753400      223   ;
0066 754400      224   ;
0069 755400      225   ;
006C 753500      226   ;
006F 754500      227   ;
0072 755500      228   ;
0075 753600      229   ;
0078 754600      230   ;
007B 755600      231   ;
007E 7537FF      232   ;
0081 7547FF      233   ;
0084 7557FF      234   ;
0087 75E02C      235   ;
008A 75F002      236   ;
008D D2DE        237   ;

DATA_2          -57H
EQU             49H
EQU             2CH
EQU             02H

INITIALIZATION
=====
MOV SP, #5FH
MOV CMOD, #00H
MOV CON, #00H
MOV CH, #00H
MOV CL, #00H
MOV CCAP3, #S_W_TIMER
MOV IE, #0D8H
MOV SCON, #50H
MOV PCAP2H, #0FFH
MOV PCAP2L, #00CH
MOV I2CON, #34H

CLR TXM_START_BIT_0
CLR TXM_START_BIT_1
CLR TXM_START_BIT_2
CLR TXM_IN_PROGRESS_0
CLR TXM_IN_PROGRESS_1
CLR TXM_IN_PROGRESS_2
MOV TXM_BUF_0, #00H
MOV TXM_BUF_1, #00H
MOV TXM_BUF_2, #00H
MOV TXM_REG_0, #00H
MOV TXM_REG_1, #00H
MOV TXM_REG_2, #00H
MOV TXM_COUNT_0, #00H
MOV TXM_COUNT_1, #00H
MOV TXM_COUNT_2, #00H
MOV DATA_0, #0FFH
MOV DATA_1, #0FFH
MOV DATA_2, #0FFH
MOV CCAP3L, #2CH
MOV CCAP3H, #02H
SETB CR
    
```

MCS-51 MACRO ASSEMBLER	SWPORT	LOC	OBJ	LINE	SOURCE
				254	;
				255	;
				256	;
				257	;
				258	;
				259	;
008F 02009D				259	;
				260	;
0095 300408				260	;
0098 301424				261	;
009B 80F5				262	;
				263	;
				264	;
				265	;
009D C203				265	;
009F 0537				266	;
00A1 853734				268	;
00A4 853435				269	;
00A7 753609				270	;
00AA 06A4				271	;
00AC 80E4				272	;
				273	;
00AE C20B				274	;
00B0 0547				275	;
00B2 854744				276	;
00B5 854445				277	;
00B8 754609				278	;
00BB 80D5				280	;
00BD 80D5				281	;
00BF C213				282	;
00C1 0557				283	;
00C3 855754				284	;
00C6 952455				285	;
00C8 821409				287	;
00CC 8214				288	;
00CE 80C2				289	;
				290	;
				291	;
				292	;
				293	;
				294	;
00D0 C0E0				294	;
00D2 C0D0				295	;
00D4 C2DB				296	;
00D6 30041E				297	;
				298	;
				299	;
				300	;
				301	;
				302	;
00D9 200307				303	;
00DC C2B2				304	;
00DE D203				305	;
00E0 0200F7				306	;
				307	;
				308	;



```

LOC OBJ          LINE   SOURCE
00E3 D53607      309      DJNZ TXM_COUNT_0, TXM_DATA_0
00E6 D282        310      ; If bit count equals 1 thru 9,
00E8 C204        311      ; transmit data bits (8 total)
00EA 0200F7      312      SETB P3.2
00EB 0200F7      313      CLR TXM_IN_PROGRESS_0
00ED E535        314      JMP TRANSMIT_1
00EF 032         315      ;
00F0 032         316      MOV A, TXM_REG_0
00F1 032         317      RRC A,3
00F2 F535        318      ;
00F3 032         319      MOV TXM_REG_0, A
00F4 0200F7      320      JMP TRANSMIT_1
00F5 032         321      ;
00F6 032         322      ;
00F7 032         323      ;
00F8 032         324      ;
00F9 032         325      ;
00FA 032         326      TRANSMIT_1:
00FB 032         327      JB TXM_START_BIT_1, TXM_BYTE_1_1
00FC D283        328      CLR P3.3
00FD D208        329      SETB TXM_START_BIT_1
00FE 020118      330      JMP TRANSMIT_2
00FF D208        331      ;
0100 D54607      332      DJNZ TXM_COUNT_1, TXM_DATA_1
0101 020118      333      ;
0102 D283        334      SETB P3.3
0103 C20C        335      CLR TXM_IN_PROGRESS_1
0104 020118      336      JMP TRANSMIT_2
0105 E545        337      MOV A, TXM_REG_1
0106 12         338      RRC A,3
0107 D283        339      ;
0108 020118      340      MOV TXM_REG_1, A
0109 F535        341      JMP TRANSMIT_2
010A 032         342      ;
010B 032         343      ;
010C 032         344      ;
010D 032         345      ;
010E 032         346      ;
010F 032         347      TRANSMIT_2:
0110 032         348      JB TXM_START_BIT_2, TXM_BYTE_2_1
0111 C204        349      CLR P3.4
0112 D213        350      SETB TXM_START_BIT_2
0113 F535        351      JMP TXM_EXIT
0114 020139      352      DJNZ TXM_COUNT_2, TXM_DATA_2
0115 020139      353      ;
0116 D284        354      SETB P3.4
0117 C204        355      CLR TXM_IN_PROGRESS_2
0118 020139      356      JMP TXM_EXIT
0119 020139      357      ;
011A 020139      358      MOV A, TXM_REG_2
011B 13         359      RRC A
011C 032         360      MOV P3.4, C
011D 020139      361      MOV TXM_REG_2, A
011E 020139      362      JMP TXM_EXIT
011F 032         363      ;

```

```

MCS-51 MACRO ASSEMBLER      SNEORT
LOC OBJ      LINE      SOURCE
0139 C3      364      CLR C          ; Update compare value with
013A 742C    365      MOV A, CCAP3L ; full bit time = 22CH
013B 256D    366      ADD A, CCAP3L
013C F56D    367      MOV CCAP3L, A
013D F56D    368      MOV A, #FULL_BIT_HIGH
013E 35FD    369      ADDC A, CCAP3H
013F 35FD    370      MOV CCAP3H, A
0140 D0D0    371      POP PSW
0141 D0D0    372      POP ACC
0142 D0D0    373      RETI
0143 D0D0    374      ;
0144 32      375      ;
0145 32      376      ;
0146 32      377      ;
0147 32      378      ;
0148 32      379      ; When a byte is received on the full-duplex serial port, it is then
0149 32      380      ; transmitted back to a "dummy" terminal. This terminal checks that
014A 32      381      ; the byte it transmitted to the PCA is the same value it receives back.
014B 32      382      ;
014C 32      383      ;
014D C0E0    384      SERIAL_PORT:
014E C0E0    385      PUSH ACC
014F 30980B  386      JNB RI, TXM ; Check whether RI or TI
0150 E599    387      MOV A, SBUF ; caused the interrupt
0151 C298    388      CLR RI
0152 4359    389      MOV SBUF, A
0153 4359    390      POP PSW
0154 D0E0    391      POP ACC
0155 32      392      RETI
0156 32      393      ;
0157 C299    394      TXM:
0158 D0D0    395      POP PSW
0159 D0E0    396      POP ACC
0160 32      397      ;
0161 32      398      ;
0162 32      399      ;
0163 32      400      END

REGISTER BANK(S) USED: 0
ASSEMBLY COMPLETE, NO ERRORS FOUND
    
```